ERGO1

» INSTRUCTIONS OF USE












X Do not use as a step ladder



Use soft tyred castors for tiles Use hard tyred castors for carpet

- Vacuum regular
- Regularly adjust mechanism angle
- Regularly adjust gas height
- All warranty claims to be forwarded to place of purchase
- Warranty covers components and workmanship only
- Damage or wear and tear not covered by warranty
- Misuse or abuse will not be covered under warranty