

## » INSTRUCTIONS OF USE



**X** Do not use as a step ladder

### INDOOR USE ONLY

To adjust back height  
hold back with two hands  
while seated and raise to  
desired height


To lower the back height  
raise back all the way to  
the top and release slowly

**RIGHT BACK KNOB**  
To adjust seat depth  
(seat slider)

**RIGHT BACK LEVER**  
To adjust back angle

**RIGHT MIDDLE LEVER**  
To adjust seat angle

**RIGHT FRONT LEVER**  
To adjust seat height



**ADJUSTABLE ARMS**

### **700MM ALUMINIUM 5 STAR BASE WITH CASTORS**

Use soft tyred castors for tiles

Use hard tyred castors for carpet

- » Vacuum regular
- » Regularly adjust mechanism angle
- » Regularly adjust gas height
- » All warranty claims to be forwarded to place of purchase
- » Warranty covers components and workmanship only
- » Damage or wear and tear not covered by warranty
- » Misuse or abuse will not be covered under warranty