



X Do not use as a step ladder

To adjust back height
hold back with two hands
while seated and raise to
desired height
To lower the back height
raise back all the way to
the top and release slowly

ADJUSTABLE ARMS

RIGHT BACK LEVER

To adjust back angle

RIGHT 3RD LEVER

To adjust seat angle
(backwards)

RIGHT 2ND LEVER

To adjust seat height

RIGHT FRONT LEVER

To adjust seat angle
(forwards)

FRONT KNOB

To adjust weight tension

700MM BLACK NYLON 5 STAR BASE WITH CASTORS

Use soft tyred castors for tiles

Use hard tyred castors for carpet

- » Vacuum regular
- » Regularly adjust mechanism angle
- » Regularly adjust gas height
- » All warranty claims to be forwarded to place of purchase
- » Warranty covers components and workmanship only
- » Damage or wear and tear not covered by warranty
- » Misuse or abuse will not be covered under warranty