

ERGO-1 RANGE

INSTRUCTION OF USE

To adjust back height hold back with two hands while seated and raise to desired height

To lower the back height raise back all the way to the top and release slowly

RIGHT BACK LEVER

To adjust seat depth (seat slider)

RIGHT FRONT LEVER


To adjust seat height

RIGHT KNOB

To adjust weight tension

700MM ALUMINIUM 5 STAR BASE WITH CASTORS

Use soft tyred castors for tiles
Use hard tyred castors for carpet



INDOOR USE ONLY

X Do not use as a step ladder

DIMENSIONS: (mm)

BACK
W: 530
H: 640

BACK TO FLOOR
Lowest: 1110
Highest: 1190

HEADREST
W: 300
H: 180

HEADREST TO FLOOR
Lowest: 1245
Highest: 1400

SEAT
W: 520
D: 500

SEAT TO FLOOR
Lowest: 500
Highest: 590

ARM TO FLOOR
Lowest: 660
Highest: 820

** Please note that the Headrest should not be used to manoeuvre the chair.*



ERGO-1H



ERGO-1L



Back view



Features:

- Adjustable seat height cable controlled
- Adjustable back height (ratchet)
- Adjustable seat and back angle cable controlled
- Adjustable seat depth (seat slider) cable controlled
- Adjustable weight tension
- Adjustable active lumbar

- 2-Way adjustable arms
- Synchron mechanism with 3 locking positions
- 700mm aluminium 5 star base
- Available in black only
- BIFMA tested
- Suitable for indoor use only