

OYSTER RANGE

INSTRUCTION OF USE

To adjust back height hold back with two hands while seated and raise to desired height

To lower the back height raise back all the way to the top and release slowly
(LOW BACK ONLY)

RIGHT BACK KNOB

To adjust seat depth (seat slider)

RIGHT BACK LEVER

To adjust back angle

RIGHT MIDDLE LEVER

To adjust seat angle

RIGHT FRONT LEVER


To adjust seat height

700MM ALUMINIUM 5 STAR BASE WITH CASTORS

Use soft tyred castors for tiles
Use hard tyred castors for carpet

INDOOR USE ONLY

ADJUSTABLE ARMS



X Do not use as a step ladder

DIMENSIONS: (mm)

LOW BACK		MEDIUM BACK		HIGH BACK		SEAT		ARM TO FLOOR	
BACK	BACK TO FLOOR	BACK	BACK TO FLOOR	HEADREST	TO FLOOR	W: 500	SEAT TO FLOOR	Lowest: 660	
W: 500	Lowest: 910	W: 500	Lowest: 1040	W: 345	Lowest: 1180	D: 470	Lowest: 480	Highest: 810	
H: 500	Highest: 1045	H: 660	Highest: 1130	H: 170	Highest: 1360		Highest: 570		

** Please note that the Headrest should not be used to manoeuvre the chair.*



OYEX1-H



OYEX1-M



OYEX1-L

Features:

Adjustable seat height
Adjustable back height (ratchet)
(Available in low back only)
Adjustable seat and back angle

Adjustable seat depth (seat slider)
Adjustable arms
Moulded seat foam
4 lever ergonomic mechanism

700mm aluminium 5 star base
Available in black only
Suitable for indoor use only

