

TASK MESH SEATING

BREEZE RANGE



BREEZE



BREEZE-A



Back view

Features

- New fully ergonomic mechanism with improved 3 lever access and seat slider
- Adjustable seat height
- Adjustable back height (ratchet)
- Adjustable back and seat angle
- Adjustable weight tension
- Adjustable seat depth (built-in seat slider)
- Adjustable lumbar
- Mesh back
- Square seat
- Moulded seat foam
- 680mm black nylon 6 star base
- Not available with drafting kit
- Available in Metro black only

Instruction of use

✗ Do not use as a step ladder

To adjust back height
hold back with two
hands while seated and
raise to desired height

To lower the back
height raise back all
the way to the top and
release slowly

Right back lever


To adjust back angle

Right middle lever

To adjust seat angle

Right front lever

To adjust seat height




Left Lever

To adjust seat depth
(Build-in seat slider)

Front knob

To adjust weight tension

Dimensions (mm)



Options



Brake castor

Brake castor for
hard/ soft floor



Glides

Chair glides



KENARM

Adjustable arms